* Remove all existing circuitry and concrete bases with the outlets
* All new PVC conduits shall run underground

* Install new water proof outlets and weather proof enclosures for the new home run.
* Install GFCI's in the new iunction box - 2nos
* Intercept the existing home run for new connections.